

TEARDROP

HARP LYRE

Hello and thank you for your purchase of the Teardrop Harp Lyre from PurpleHarp Productions!

To get started, you will need to tune your Lyre.

Get acquainted with the names of the strings for best results.

From the lowest/longest string to the highest/shortest, the names of the strings are as follows:

G,A,B,C,D,E,F,G,A,B,C,D,E,F,G,A

Use a chromatic electronic tuner or tuning app to assist with tuning.

Your tuner should have a number in the corner that reads 440Hz.

The goal is to get the needle in the center for each string.

Pluck the string and check the tuner to see if it is in tune. If it is, the needle will be in the center and read the correct note name. Ex) tuning the Red C string, the tuner should read C and needle in the center.

If the tuner needle leans to the right, the string is sharp. You will need to lower (loosen) the string.

Use your tuning key on the tuning pin and turn it in very small increments counter-clockwise.

If the tuner needle leans to the left, the string is flat and needs to be raised (tightened). Use your tuning key on the tuning pin and turn in very small increments clockwise.

Tune every string.

Your Teardrop Harp Lyre should be tuned regularly and as needed.

Teardrop Harp Lyre



If you need additional information or help, please contact us at purpleharp@live.com. Tutorials and music are available at www.youtube.com/@purpleharpproductions. Sheet music and instruments are available at www.purpleharp.com. Private lessons are available by contacting us at purpleharp@live.com, please type LESSONS in the subject.

Share your experience with us on instagram! @purple_harp

Happy Harping!